# **TALKING PENGUIN CLOCK**



### **Function Descriptions**

Talking time, alarm with different sounds, snooze, and hourly chime.

#### **Battery Replacement**

Open the battery cover and insert two new AAA batteries in the correct orientation.

### Modes

Press the MODE button, located on the back of the penguin to change the functional modes according to the following order:

- Normal Time Display Mode
- Time Setting Mode
- Alarm Setting mode

# To set time

Starting from time display mode, press MODE to enter time setting mode. Press MIN, HR buttons (the left and right penguin arms) to adjust minutes and hours respectively to the appropriate time.

## To set Alarm time

Starting from time display mode, press MODE twice to enter alarm setting mode. AL symbol will display with blinking numerals. Press MIN and HR (penguin arms) to adjust minutes and hours respectively to the appropriate alarm time.

# Choose the alarm sound and turn the alarm on or off

In normal time display, press HR button to choose the alarm sound and to turn the alarm on or off. When setting the alarm sound, it will play the alarm sound and turn on the alarm. The alarm time will be shown on the display after playing the alarm sound. The display then returns to the normal time display. To turn the alarm off, scroll through the alarm sounds till there is no sound.

### Turn on / off the Hourly announce

Starting from the time display mode, press MIN to turn on or off hourly announcement (no symbol).

# **Snooze function**

When the alarm sounds, press TALKING to stop the alarm and start the snooze function. The alarm will sound again every five

minutes after the snooze starts. The alarm sound will repeat no more than six times.

### Listen to the alarm sound

In normal time display mode, press and hold TALKING button. It will play the alarm sound after speaking the current time.