



iTalk Reminder Assistant

Reminder Rosie

The Reminder Assistant

Quick Start Guide

This quick start guide is broken down into five sections

Part. 1- Opening the package

Part. 2- Buttons on the backside of Rosie

Part. 3- Setting Rosie

Part. 4- Operating Rosie

Part. 5- The importance of the batteries

Part. 1- Opening the package

1. Plug Reminder Rosie into an AC outlet.

You should find the clock status as the following

- a. The default time will be set at 12:00AM.
- b. Alarm and Trigger indicator should be set in the on position.
- c. Rosie will come with three AAA sized batteries already installed through the bottom of the clock.
- d. The date will be preset for your convenience.
- e. Rosie's microphone is positioned centered in the front bottom of the clock. Nothing should be a direct obstruction that can muffle the microphone and prevent the clock from hearing your spoken words.
- f. So long as the batteries have a charge, the information in the clock will be stored.

Part. 2- Buttons on the backside of Rosie

Hold Rosie with the front side facing you. The AC wire will be on the backside of the clock. Towards the top on the backside you will feel 7 buttons. With the clock facing forward to you, starting from the far left side, the seven buttons are as follows:

Button 1- Volume button that slides left or right. In the slide left position it is low volume, and positioned to the right is high volume.

Button 2- Dimmer Button that slides left or right. This button is for use for people with partial or full sight. The bright 2 inch high LED lighted numbers can be set on low with this button positioned to the left, or high with the button positioned to the right.

Button 3- Is a manual operational button that pushes in (as oppose to sliding left and right). This button can be used to manually set the clock. Button 3 changes the numbers down. Button 3 is most important for you if you need to reset the date.

Button 4- This is the center button- Like button 3, it is used for manual settings and this button changes numbers up.

Button 5- Is the mode button. This is also used for manual settings for time and date. You should avoid using this button and only rely on spoken words to operate the clock. If the date needs to be reset, it is recommended that you have the assistance of a person with vision.

Button 6- This is the second button from the right side. This is the trigger mode button and pushes in as oppose to sliding from side to side. The trigger mode should be ON when you remove the clock from the packaging. When you push the trigger button the clock will announce if the trigger mode is set to ON or OFF. You need the trigger mode ON to have the clock respond to your voice commands.

Button 7- This is the button to the far right side and slides left and right. This is the Alarm button. To have the alarm set in the ON position the slide button should be positioned to the right. To turn off the alarm you may position this slide button to the left. The clock will announce if the alarm is ON or OFF when you switch this button's setting.

Part. 3- Setting Rosie

1. Speak facing Rosie from arms length, in normal conversational voice and without background noises. Do not speak when Rosie is talking.

2. To set the time, alarm, or record a reminder, or any command or question, you need to wake up Rosie (Trigger button must be set to ON). Waking Rosie can be done in two ways:

1. Say "**Reminder Assistant**" *or*
2. Push down on Rosie.

Rosie will then respond "**Can I help you**". Now you have 3 seconds to say a command or question.

3. To start off, ask Rosie to tell you all commands and questions she understands. Wake up Rosie by speaking the words "Reminder Assistant" or push down on Rosie. Rosie will say "Can I help you?" and then say the word "**help**".

4. Now to set the time. As always wake up Rosie first, and then say "**set time**", and follow Rosie's prompts. Rosie will repeat what you set as the time so if Rosie didn't hear the time correctly, just repeat this step.

5. Now to set the alarm time. As always wake up Rosie first, and then say "**set alarm**", and follow Rosie's prompts. Rosie will repeat what you set as the time so if Rosie didn't hear the time correctly, just repeat this step.

6. Now to set the alarm sound. As always wake up Rosie first, and then say "**alarm sound**", and follow Rosie's prompts. Rosie will confirm the alarm sound you requested.

7. Now set a reminder. Wake up Rosie & say "**Record reminder**" & follow the prompts.

- Maximum 6 second reminders can be set for everyday, any day of the week or today only Reminders need only be set once for everyday or any day of the week only week.
- Reminders alarms go off for 30 minutes, and can be heard 100 feet away (Hi Volume setting). To turn the reminder off wait for the silence in between the recording and

simply say "**Reminder off.**" Or to turn off the recording you can just push down on Rosie.

o To erase reminders say "**Play Reminders**" and follow prompts.

8. You can always push Rosie down to stop her from speaking to cancel out of a command.

9. To re-set the date, please request assistance from a person with sight and refer to the printed instructions included with the original packaging.

Part. 4- Operating Rosie

1. You can speak to Rosie from distances of across a large room. Do not speak when Rosie is talking. If there are background noises like a television, this can affect Rosie's ability to understand you clearly. Occasionally from time to time Rosie can also wake up when something is said on a television or radio that Rosie mistakenly thinks you are saying "Reminder Assistant." Don't worry, if Rosie wakes up unintentionally, she will shut off automatically after a few seconds if nothing else is said. Or you can always say the word cancel to turn Rosie back to sleep mode. Rosie will say goodbye once she hears your command to cancel.

2. You can ask Rosie questions like-

a. What time is it?

b. What time is the alarm set for? Side note here- Rosie will tell you the time the alarm is set for and whether the alarm is set to On or off.

c. What day is it? -- Side note here- Do not ask "What is today's date?" Stick to the question "What day is it?" and Rosie will properly respond.

d. Play Reminders. Side note here- It is during the play reminder mode you can erase reminders.

3. Rosie likes a conversational tone in your voice- It is suggested not to try too hard to pronounce each word. Just speak to Rosie in regular conversational tone and she will operate the best.

Part. 5- The importance of the batteries

1. Your clock will include the batteries already installed for your convenience.

2. The batteries are important to store your programmed settings of the clock. This is important for when you unplug and move the clock or if you experience a power outage.

3. This is very important because if the batteries are not in place you will be required to re-set the date. This will likely require the assistance of someone with sight.

4. If you wish to ensure the batteries are fresh we recommend that you change the batteries while the clock is plugged in the AC so that the date setting is not lost.

QUESTIONS?

Call your Sales Associate Larry at 818-602-8675

Or

Customer Service toll free at 1-855-371-3320

Or

Email to Larry@lifeassisttech.com