

Please read carefully

Two light bulbs and one 5 inch diameter lens are packed in all cartons.

Assembly

A. Model 310 Floorlamp

Insert threaded portion of bottom pipe through hole in base. Slide lock washer over end of pipe, attach lock nut and tighten. To adjust height, loosen collar joining the upper and lower sections. Raise upper assembly to desired position and retighten collar. If it is necessary to disassemble the upper and lower pipes, take care not to lose the small plastic ring inside the collar. When replacing plastic ring, it works best with the bevelled side up.

Model 518/3518 Floorlamps

Stand base on edge. Slide lockwasher over bolt, Insert bolt through hole in the base, align with the bottom of the lamp and thread together. Both of these models have an auto-clutch assemble built in for height adjustment.

<< Continue with the following steps. >>

B. Lens Assembly (All models)

Proper care must be taken to prevent scratching your magnifier. Remove lens from carton. (With models 010, M14, and 1418, this is inside the flap on the inside right of the carton). Remove bolt and wing nut from lens-support tongue. Insert lens-support tongue into slot in lens. Make sure holes in both lens and support tongue line up. Insert bolt from top through holes in both lens and support. Attach wing nut to bolt and finger tighten until lens is stable. (Do not over tighten as this could damage your lens)

LS&S, LLC
145 River Rock Dr
Buffalo, NY 14207-2172

C. Lens Care

Your lens is a precision product molded from ophthalmic grade acrylic and is hard coated. With proper care it will last indefinitely. Make certain your lamp is unplugged while cleaning lens. Never clean your lens by wiping it with a dry cloth or tissue paper. We do not recommend window cleaner as this could ruin your lens.

We recommend a soft cloth dipped in warm soapy water. Rinse with clean water and dry with facial quality tissue. (Do not use paper towels). A quality plastic polish could be used.

These precautions are necessary to protect your lens from scratching or distortion. The lens is replaceable -but not under warranty.

D. Proper Use

Position your Lamp so that you are looking through the lens. Adjust lamp up or down as needed to bring subject matter into sharp focus, then turn lamp on. Take care that shade or light bulb is not touching fabric, paper, etc.

E. Precautions

Keep lamp out of direct sunlight, as the sun's rays could be concentrated by the lens and start a fire. Grasp lamp by shade to position lens for use. Never adjust lamp by twisting the lens. Always position lamp with clearance for heat ventilation. The bulb gets hot and could damage fabric, etc. if too close. With prolonged use, the shade will get warm to the touch. When this happens, you may detect a slight odor. This is normal. Always allow your lamp to cool off before covering the lens.

F. Warranty and Service

All Big Eye products are warranted against manufacturing defects for a period of one year from date of purchase.

Lenses and bulbs are not under warranty. Your warranty will be void if malfunction results from damage or unreasonable use while in your possession.

G. To Return Lamp For Service

Prior to any returns, you must contact us for a return authorization number. This must be written on the outside of the carton, or lamp will be refused.

Remove lens, lens hardware, and lightbulb from the lamp, the base and hardware from floor models.

(Do not return these items).

Pack the lamp in a carton stuffed with newspaper to prevent damage.

◀over▶

For repair information call:

Big Eye Lamp, Inc.

732-557-9400

Fax: 557-9111

Infobigeye@aol.com

Do not forget to enclose a short note with the following information:

Your name and complete address

(we cannot ship to a Post Office Box)

Telephone number and a brief description of the problem.

Other fine Big Eye Products

<u>Model</u>	<u>Description</u>
010	Table Lamp with magnifier
310	Floor Lamp with magnifier
L-465	Lens Power Booster Assembly
L-575	Replacement Lens
PL-40	Replacement Bulb
M14	Free standing magnifier
1418	Deluxe 2 arm Table Lamp
518	Deluxe Floor Lamp
3518	Two arm Deluxe Floor Lamp