
Item Number

ONE BUTTON TALKING ANALOGUE WATCH INSTRUCTION SHEET



(1) BASIC FUNCTION FOR PUSH BUTTON AND CROWN:

Crown - adjusts hour and minute hands.

- located at 3:00 on the watch case

Button1 - Talking function button. Press down to Announce time. "The time is 2:45 pm".

- located at 2:00 on the watch case

Button2 - Minute setting button.

- is recessed and requires a pen tip to set minute time.
- located at 4:00 on the watch case

Button3 - Hour setting button.

- is recessed and requires a pen tip to set hour time.
- located at 8:00 on the watch case

(2) INSTRUCTION:

- 1. ACTIVATED THE WATCH FROM SLEEPING MODE:
 - Hold S1 for 5 secs until a "DO" sound to activate the watch from sleeping mode.
 - Hold S1 for 5 secs until a "DO" sound to enter the sleeping mode.

2. SET HOUR AND MINUTE HANDS:

-Pull crown out slightly to manually operate hands. Set hour and minute hands to desired setting. When completed, then push back the crown to normal position.

3. SET TALKING TIME PROCEDURES:

- -Apply pen tip to recessed button S2 to set minute time.
- -Apply pen tip to recessed button S3 to set hour time.