



simplTM TV Remote

Television Setup



simplTM TV Remote

Cable or Satellite Setup



simplTM TV Remote

Favorite Channel Setup

STEP 1

Press & hold 'C'
until the LED
flashes

STEP 2

Press & release
'Favorite 1'

1

STEP 3

Input the channel
; A for 1,000,
then 100, 10
& 1 buttons

STEP 5

Press 'Favorite 1'.
If the channel
changes your
all set!

STEP 4

Quickly press
'Favorite 1' & then
quickly press
'C'

