

INSTRUCTION OF YL-3026C LCD TALKING CALCULATOR WITH CHECK BACK FUNCTION

This calculator runs on 2 AA batteries.

model 241010

Headphone can be plugged into the headphone jack on the left side of the calculator (optional).

Calculator Function

LS&S, LLC
145 River Rock Dr
Buffalo, NY 14207-2172

KEY	FUNCTION
AC/ON	POWER ON The calculator is set to be auto power off after 5 minutes, press "AC/ON" again to turn it on ALL CLEAR Clear all equations entered
REPEAT	REPEAT the displayed value
VOLUME	VOLUME CONTROL There are three levels for volume control: mute, soft or loud
←CHECK	CHECK BACK FUNCTION (BACKWARD) Back to an equation entered (backward)
→CHECK	CHECK BACK FUNCTION (FORWARD) Back to an equation entered (forward)
CORRECT	CORRECT the value entered For example: $1 + 2 + 9 + 4 + 5$ Press ←CHECK or CHECK to go back to 9, then press "CORRECT", "3", "CORRECT" to change the equation to $1 + 2 + 3 + 4 + 5$
+	PLUS
-	MINUS
x	TIMES
÷	DIVIDED BY
%	PERCENTAGE
←	BACKSPACE Clear the last digit of the value entered
=	EQUAL
M+	MEMORY PLUS Add to memory
M-	MEMORY MINUS Subtract from memory
GT	GRAND TOTAL
MRC	MEMORY CLEAR
AUTO REPLAY	AUTO PEPLAY Replay equation
UNIT	UNIT Result can be reported with or without unit
+ / -	+ / - Set positive or negative value
C/CE	CLEAR Clear the value entered

LS&S, LLC
1-800-468-4789
1-716-348-3500
1-877-498-1482 Fax
www.LSSproducts.com

