

TAYLOR[®]

Leading the Way in Accuracy[®]

Model

481071

Electronic Scale with Voice Feature Instruction Manual

Thank you for purchasing a Taylor[®] Electronic scale. All of our precision instruments for weight measurement are engineered and designed to meet the highest quality standards to assure you years of uncompromising accuracy and consistently dependable, convenient performance.

These instructions contain important and useful information about this unit's operation. Please read instructions thoroughly to ensure that you have the full benefit of all the unit's features.

Keep these instructions handy for future reference.

Battery Installation

1. Use 3 AAA batteries (included. Remove any plastic wrap from the batteries before proceeding). Always replace all batteries at the same time; do not combine old and new batteries. Do not mix Alkaline, carbon-zinc (standard) or Nickel-Cadmium (rechargeable) batteries.
2. Remove the battery compartment cover on the bottom of the scale.
3. Place the batteries into the battery compartments according to the "+" and "-" polarity symbols at the bottom of the compartment.
4. Replace the battery compartment cover.
5. Replace all the batteries if "LO" is displayed and the scale says "Low Battery", LCD readings grow dim or irregular, or the voice quality distorts or becomes too soft to hear.

NOTE: Please recycle or dispose of batteries per local regulations.

WARNING: Batteries may pose a choking hazard. Do not let children handle batteries.

General Operation

1. Install 3 AAA batteries (please see "Battery Installation" section of this manual). Also, some models have a static cling label on the lens to prevent scratching. Remove before use.
2. Select language of English, Spanish, German, Greek or Croatian by pressing the button on the side of the scale. The scale will speak the corresponding language once the language is selected. **(Note: Pound units of measurement will be spoken in English. Spanish, German, Greek and Croatian will be spoken in kilograms.)**
3. Select a volume level of high, low or off by moving the volume dial slide switch on the side of the scale. To turn the voice function off, turn the dial until it clicks off.
4. Place scale on flat, hard surface. Carpeted or uneven floors may affect accuracy.
5. Press firmly on the scale platform. The scale turns on, beeps and says "Ready for operation." This process insures the scale is set and is now ready for use. Do this whenever the scale is moved. At all other times step straight onto the scale.
6. Step onto the scale platform and remain still. The display will count up to your weight. The display will flash twice when the weight is locked. Your weight is now displayed and you will hear your weight.
7. When you step off of the scale, the scale will say "Ready for operation" and automatically turn off. If you continue to stand on the scale, the scale will beep twice and automatically turn off.

NOTE: If you've weighed yourself and the message "Err" is displayed with sound "Error", simply step off of the scale and repeat the weight measurement procedure while standing still. Your weight cannot be locked in if you do not stand still.

Trouble Shooting

1. Place your feet in the same position every time you weigh yourself. Stand still during measurement.
2. Weigh yourself without clothing whenever possible. Clothes can vary in weight.
3. Move the scale to a location where it won't be bumped. If your scale is bumped while being activated or while in use, an inaccurate reading may occur.
4. For the most consistent readings, weigh yourself at the same time of day.
5. The maximum capacity of this scale is 440 lb / 200 kg. Should "O-Ld" appear on the display during a weighing, this indicates that the maximum weighing capacity of the scale has been exceeded. Remove the weight immediately; otherwise, permanent damage may occur.

Precautions

- 1.** Clean exposed parts with a soft, slightly damp cloth. To remove stains, use a mild soap. Never use detergents, excess water, treated cloths, harsh cleaning agents, or sprays. Do not attempt to lubricate or open scale casing.
- 2.** Although your scale is designed to be maintenance-free, it contains sensitive electronic parts. Avoid rough treatment. Do not drop, kick, or jump on it. Treat it with care to ensure the best performance.
- 3.** This scale is designed to read weights between 6.6 and 440 lb/ 3 and 200 kg. To prevent damage do not place more than 440 lb / 200 kg on it.
- 4.** Do not store scale where you store cleaning chemicals. The vapors from some household products may affect the electronic components of your scale. Do not store scale on its side.
- 5.** This scale is an extremely sensitive weighing device. In order to prevent run down of the battery, do not store anything on the scale.
- 6.** Do not dispose of batteries in fire. Batteries may explode or leak. Do not mix Alkaline, carbon- zinc (standard) or Nickel-Cadmium (rechargeable) batteries. Remove the batteries if the scale will not be used for a long period of time.

Note:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Five (5) Year Limited Warranty

This scale is warranted against defects in materials of workmanship (excluding batteries) for five (5) years for the original purchaser from date of retail purchase. It does not cover damages or wear resulting from accident, misuse, abuse, commercial use, or unauthorized adjustment and/or repair. Do not return to retailer. Should this scale require service (or replacement at our option) while under warranty, please pack the item in the original packaging and return it prepaid, along with store receipt showing date of purchase and a note explaining reason for return to:

Taylor Precision Products, Inc.
2220 Entrada Del Sol, Suite A
Las Cruces, New Mexico 88001 USA
www.taylorusa.com

There are no express warranties except as listed above. This warranty gives you specific legal rights, and you may have other rights which vary from state to state.