

**INSTRUCTION OF YL-3019 LCD TALKING CALCULATOR****Time display:**

Press "TIME" key to enter time display mode. Turn volume to Lo or Hi to hear time.

Example: "The time is 3:20p.m." (12-hour mode)

"The time is 15:20" (24-hour mode)

Press "SET" key to enter time setting mode. When LCD shows "SET", press "HOUR" or "MIN" to adjust time (Seconds will reset to 00 when "MIN" is set). Press "SET" key again exit the setting mode.

Press "%" key to switch between 12 and 24 hour mode.

**Alarm time display**

Press "ALM" key to enter alarm display mode. Turn volume to Lo or Hi to hear alarm time. Press "SET" key to enter alarm time setting mode. When the LCD shows "ALM SET", press "HR" or "MIN" to adjust the alarm time. Press "SET" key again to exit alarm setting mode.

Press "ALM ON" to set alarm "ON" or "OFF", -LCD will display "((( )))" when alarm is set to ON.

When alarm sounds, press any key to stop.

**Music Function**

In time mode, press 0 thru 9, = + - × / . " keys to play music (16 melodies)

Music will automatically stop after playing once.

Press any other key to stop the music.

**Calculator Function**

Press "CE" or "AC" key to enter calculator mode.

Press "REP" key to repeat the displayed value.

Press "U/D" key to express Value or Digits of display.

Press "MR" key to show memory contents. MC clears, M+ adds to and M- subtracts from memory. Use M+ or M- instead of = to enter result directly to memory.

In "Time Setting" and "Alarm Display" modes, 16 seconds idle will automatically return to time display. Calculator idle 4 minutes also returns to time display mode.