

## **T-10A Pyramid Talking Alarm Clock**

### **TO INSERT BATTERIES**

1. Open the battery door
2. Insert 4 AA batteries into the battery compartment
3. Make sure the battery polarities are correct.

### **TO SET THE TIME**

1. Move the switch B to "Time Set " position
2. Press "HR" button to increment hours
3. Press "MIN" button to increment minutes
4. Once desired time reached, slide switch B to center position.

### **TO HEAR TIME ANNOUNCEMENTS**

1. Press the "TALK" button to hear a pleasant female time announcement

### **TO SET THE ALARM TIME**

1. Move the switch B to "ALM SET " position
2. Press "HR" button to increment alarm hours
3. Press "MIN" button to increment alarm minutes
4. Once desired alarm time reached, slide switch B to center position.

### **TO TURN ON THE ALARM**

1. Move the switch C to "ALARM ON " position to turn on the alarm

### **TO SELECT THE ALARM SOUNDS**

1. Switch B in the center position, press "HR" button to select the alarm sound ( Dee, Cuckoo or Rooster )

### **TO TURN OFF THE ALARM**

1. When alarm is on, press "HR" or "MIN" button to turn off the alarm.
2. Or Slide the switch B to "ALARM OFF" position

### **TO ENTER SNOOZE MODE**

1. When alarm is on, press "TALK" button to enter snooze mode, the alarm will be on 10 minutes later.

### **TO CHANGE THE VOLUME LEVEL**

1. Slide the switch A to "VH" position for maximum volume
2. Slide the switch A to "VM" position for medium volume
3. Slide the switch A to "VL" position for low volume

### **REPLACING BATTERIES**

NOTE: It is time to change the batteries when the talking sound begins weak.