

101077

LS&S, LLC
145 River Rock Dr
Buffalo, NY 14207-2172

MONEX

Atomic Talking Alarm Clock

TKC105U


INSTRUCTION MANUAL

Thank you for purchasing the MONEX product.
For the correct use of the product, please
read this instruction manual before using
the unit, and keep this instruction manual
for future reference.


The radio controlled clock works on the principle of receiving time signals from the WWVB time signal broadcasting station. If time signal can be received, the clock will be synchronized with the time of the US Atomic Clock and change to standard time / daylight saving time automatically. To enhance good receiving condition, avoid placing the unit near television sets, metal surfaces, computers or electric devices as these equipment will interfere the reception of radio signals.

Features:


- Full range human voice time and date announcement, with smooth and natural sound quality.
- Atomic Clock. Change to standard time / daylight time automatically.
- Display time with running second, month, date, day-of-week and alarm time.
- Hourly time announcement between 8AM to 10PM inclusively. User can select to turn on or off the hourly announcement.
- Extra long 5 minute alarm sound, with beep tone and current time announcement.
- 5-minute snooze function.
- Soft and bright backlight.
- high and low announcement volume selection.
- Button lock function.



Top View



Side View



Back View

Battery installation and replacement

The unit uses 2 pieces of AAA (or equivalent) batteries. To install or replace batteries, please slide open the battery compartment (located at the bottom of the unit) by following the direction of the arrow mark. Insert the batteries by following the polarity marked and press the RESET BUTTON once. Close the battery cover and the unit is ready for use now.


When the display (or backlight) is dim or the sound quality drops, it means the battery power is not enough. Please replace both batteries with new ones.

To reset the unit, press the RESET BUTTON once (located inside the battery compartment).

CAUTION :

Never mixed different type of batteries nor old with new batteries.

Receive the time radio signal

The unit will search for time radio signals automatically when it is powered on. The radio signal mark on the right of the time digits () will start pulsing to show that receiving is under progress. If time signal is received, synchronization will take 3-15 minutes and the unit will show the received time. The radio signal mark will show three solid bars (pulsing stopped) and stay on the display to indicate that reception is successful.

NOTES:

1. During radio signal reception, if setting time or calendar is done, radio signal reception will be terminated immediately.
2. To re-start the signal reception manually, press the SET/RECEIVE BUTTON (a beep sound will be emitted).

ATTENTION:

During daytime, there may be too much external interference that makes reception failed. Under such situation, please set the time manually because:

The unit has an automatic process to start reception, when the clock is showing time between 2-6am. At midnight, interference dropped to a minimum level and makes it a perfect environment for time radio signal reception. If the time of the clock is not set manually when it failed reception at daytime at the first time initiation, then the automatic process may start in the daytime everyday (not during midnight) and eventually keep the unit not receiving the signal.

Select the appropriate time zone

Please select the appropriate time zone before reception started or, after radio signal reception is completed. Otherwise the unit may display incorrect time if the time zone was not set. Above the second digits, there are four marks "P" "M" "C" "E" representing the four time zones in US.

To set the time zone, press and hold the SET/RECEIVE BUTTON until the year digits flash ("setting year" will be announced). The unit is now in setting mode. Press the SET/RECEIVE BUTTON twice and the time zone mark will flash ("setting time zone" will be announced). Set to "P" (PACIFIC) / "M" (MOUNTAIN) / "C" (CENTRAL) / "E" (EASTERN) time zone by pushing the UP or DOWN BUTTON. After setting the appropriate time zone, press and hold the SET/RECEIVE BUTTON until the display stopped flashing ("setting complete" will be announced) to end the setting mode.

Set the time and calendar manually

Since the unit works on receiving the time radio signal, there may be locations that the signal is weak and cannot be properly received. Under such circumstance, the radio signal mark will disappear to indicate that reception is failed. Try to rotate the unit or place it in other location to achieve better reception and re-start reception again. If finally, radio signal cannot be received, time should be set manually.

To set time and calendar, press and hold the SET/RECEIVE BUTTON until the year digits flash (*"setting year"* will be announced). Press the UP or DOWN BUTTON to adjust.

Press SET/RECEIVE BUTTON once. The month and date digits will flash (*"setting date"* will be announced). Press the UP or DOWN BUTTON to adjust. Each push of the UP or DOWN BUTTON will adjust one day and the month will be changed when start or end of the month is run through.

Press SET/RECEIVE BUTTON once. The time zone mark will flash (*"setting time zone"* will be announced). Set to "P" (PACIFIC) / "M" (MOUNTAIN) / "C" (CENTRAL) / "E" (EASTERN) time zone by pushing the UP or DOWN BUTTON.

Press SET/RECEIVE BUTTON once. The hour and minute digits flash (*"setting time"* will be announced). Press the UP or DOWN BUTTON to adjust. Each push of the UP or DOWN BUTTON will adjust one minute and the hour will be changed when 00 minute is run through.

Press SET/RECEIVE BUTTON once will end the setting mode (*"setting complete"* will be announced).

During setting, press and hold the UP or DOWN BUTTON and the corresponding digits will fast advance.

Note: when setting year, date, time zone or time, the corresponding digits will be announced.

e.g. setting year to 2010: *"year two thousand and ten"* will be announced
setting date to January 10th (Saturday): *"Saturday, January tenth"* will be announced.

Setting time zone to "P" (Pacific): *"pacific standard time"* or *"pacific daylight saving time"* will be announced.


setting time to PM 2:30: *"half past two PM"* will be announced.

Set the alarm time

To start alarm time setting, press any one of the UP or DOWN BUTTON once. The alarm time digits will flash (*"alarm set"* will be announced). Another push of the UP or DOWN BUTTON will set the alarm minute, while the hour will be changed when "00" minute is run through. Press and hold the UP or DOWN BUTTON and the digit will fast advance. To end the alarm setting mode, just leave the unit (buttons) untouched for about 5 seconds.

Alarm on/off and hourly announcement

To switch on the alarm, place the ALARM SWITCH (at right side of the unit) to "ON" position. The preset alarm time (e.g. AM 6:05) will be announced (e.g. *"alarm will be on at five minutes past six AM"*) and the alarm mark is shown on the display (next to the alarm time). When current time reaches the alarm time, the unit will announce the current time with a beep tone (e.g. *"beep beep, the time is now five minutes past six AM"*) continuously for 5 minutes. To activate the snooze function, press the SNOOZE TALK (1) or SNOOZE TALK (2) BUTTON and the alarm will be stopped and resume after 5 minutes. To stop the alarm, place the ALARM SWITCH to "OFF" or "⏸" (HOURLY ANNOUNCEMENT) position.

When the ALARM SWITCH is placed to “” (HOURLY ANNOUNCEMENT) position (“*announcement on*” will be announced), the unit will announce the time at every hour during 8 AM to 10 PM. Outside this range hourly announcement is automatically shut off.

To deactivate both the alarm function and the hourly announcement function, place the ALARM SWITCH to “OFF” position.

Select the announcement volume

To select the high volume level, set the VOL (VOLUME) SWITCH to “HI” position. To select the low volume level, set to “LOW” position.

Time and date announcement

At any time (except in setting mode and when alarm is sounding), press the SNOOZE-TALK (1) or SNOOZE-TALK (2) BUTTON once, current time is announced and the display will light up; press the SNOOZE-TALK (1) or SNOOZE-TALK (2) BUTTON twice quickly, the date is announced and the display will light up.


e.g. current time and date is AM 4:02 and April 1st (Sunday).

Press SNOOZE-TALK (1) or (2) BUTTON once: “*The time is now two minutes past four hour*” will be announced.

Press SNOOZE-TALK (1) or (2) BUTTON twice quickly: “*Today's Sunday, April first*” will be announced.

Change of daylight saving time

The unit will adjust to standard time or daylight saving time automatically, when the time signal is received successfully. When it is changed to daylight saving time,

the “” mark will be shown and time is adjusted automatically.

Function Lock

When traveling, the unit can be locked to avoid setting the unit accidentally. To lock the unit, place the LOCK SWITCH to “LOCK” position. The SET BUTTON, DOWN-UP BUTTON and the SNOOZE-TALK (1) BUTTON will be deactivated. The user can still listen to the time or date by pressing the SNOOZE-TALK (2) BUTTON, when the unit is locked.

To unlock, place the LOCK SWITCH to “UNLOCK” position.

ATTENTION:

There will be certain places (especially near the eastern coast) that the radio signal is too weak to be received. Also, during daytime, there may be too much interference that makes reception failed. Under both circumstances, please set the time manually.

The unit has an automatic process to start reception, when the clock is showing time between 2-6am. At midnight, interference dropped to a minimum level and makes it a perfect environment for time radio signal reception. If the time of the clock is not set manually when it failed reception at daytime at the first time initiation, then the automatic process may start in the daytime everyday (not during midnight) and eventually keep the unit not receiving the signal.